



151

98

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0009	Cast Control Spacer	1227	Clutch Pawl Spring Retainer	1805	Worm Bushing (A)
0011	Left Side Plate Screw	1230	Drive Shaft Spacer	1910	Cast Control Cap
0015	Drag Spring Washer	1237	Worm Bushing (A) Retainer Screw	1913	Spool Assembly
0032	Bearing Retainer	1239	Pawl Cap	1915	Right Side Plate
0036	Right Side Plate Screw	1240	Line Guide	1916	Clutch Bar Support
0042	Line Guide Pawl	1241	Level Wind Guard	2003	Star Drag
0133	Worm Shaft Retainer	1243	Worm Bushing (B)	2004	Left Side Plate
0188	"O" Ring	1252	Left Side Plate Bolt Washer	2005	Drive Gear
0192	Right Side Plate Screw	1289	Star Drag Spacer	2006	Drive Shaft
0194	Ball Bearing	1327	Idle Gear	2007	Pinion Gear
0425	"E" Lock	1337	Clutch Bar Support Spacer	2008	Yoke
0586	Bolt Retainer	1338	Clutch Bar Guide (A)	2009	Clutch Cam
0609	Clutch Cam Screw	1423	Key Washer	2010	Retractor Spring
0664	Spacer (B)	1424	Drag Washer (C)	2011	Clutch Plate
0686	Idle Gear (B) Retainer	1433	Idle Gear (B)	2012	Set Plate
0795	Handle Nut Plate Screw	1435	Clutch Pawl Spacer	2013	Clutch Pawl
0799	Friction Washer	1438	Drive Shaft Bushing	2014	Clutch Pawl Spring
0830	Spacer (optional)	1448	Anti-Reverse Ratchet	2015	Worm Bushing (A) Retainer
1133	Yoke Spring	1476	Worm Shaft Spacer	2016	Forged One-Piece Frame
1201	Retractor Spring Collar	1611	Level Wind Guide	2017	Clutch Bar Guide (B)
1206	Roller Clutch Inner Tube	1692	Handle Nut Plate	2018	Quick-Fire II Clutch Bar
1207	Roller Clutch Bearing	1714	Worm Shaft	2046	Clutch Cam Retainer
1208	Left Side Plate Bolt	1715	Brake Collar (red)		
1214	Drag Washer (A)	1716	Handle Assembly		
1218	Idle Gear (A) Spacer	1788	Handle Nut	1713	Brake Collar (green)