



BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0009	Cast Control Cap	1327	Idle Gear	2007	Pinion Gear
0011	Multi Purpose Screw	1328	Drive Shaft Retainer	2019	Handle Nut Plate Assembly
0015	Drag Spring Washer	1329	Ball Bearing	2021	Handle Assembly
0031	Ball Bearing	1332	Clutch Cam Retainer	2022	Cast Control Cap
0032	Bearing Retainer	1334	Clutch Plate	2023	Spool Shaft Clip Holder
0042	Line Guide Pawl	1338	Clutch Bar Guide (A)	2024	Spool Shaft Clip
0060	Spacer (optional)	1339	Clutch Bar Bolt	2025	Idle Gear (C)
0133	Worm Shaft Retainer	1340	Level Wind Protector	2026	Worm Shaft
0188	"O" Ring	1341	Line Guide	2028	Handle Nut
0194	Ball Bearing	1342	Pawl Cap	2029	Star Drag
0425	"E" Lock	1343	Worm Bearing (A) Retainer	2030	Left Side Plate
0664	Spacer (B)	1344	"C" Lock	2031	Drive Shaft
0686	"E" Lock	1347	Level Wind Guide	2032	Worm Bushing (A)
0770	Handle Nut Plate Screw	1348	Level Wind Guard	2033	Yoke
1133	Yoke / Turnkey Pawl Spring	1351	Clutch Bar Support	2034	Clutch Cam
1201	Retractor Spring Collar	1352	Left Side Plate Screw	2035	Clutch Pawl
1206	Roller Clutch Inner Tube	1353	Spool Assembly	2036	Clutch Pawl Spring
1207	Roller Clutch Bearing	1356	Brake Case Retainer Screw	2037	One-Piece Frame
1211	Key Washer	1357	Brake Case	2038	Clutch Bar Guide (B)
1212	Drag Washer (C)	1362	Turnkey Pawl	2039	Quick-Fire II Clutch Bar
1214	Drag Washer (A)	1363	Turnkey Dial	2040	Right Side Plate Spring
1237	Worm Bearing (A) Retainer Screw	1476	Worm Shaft Spacer	2041	Right Side Plate
1243	Worm Bushing (B)	1514	Drive Gear		
1289	Star Drag Spacer	1715	Brake Collar (red)		
1319	Click Gear	1796	Retractor Spring		
1320	Star Drag Spring	1992	Spacer (B)	1713	Brake Collar (green)