


SHIMANO

SUPER ULTEGRA S A-RB

SULT-6000XSA



(1SG956000G)

| Part No. | Description | Part No. | Description | Part No. | Description |
|----------|-----------------------------|----------|----------------------------|----------|--------------------------|
| RD 0540 | Screw | RD 5698 | Bail Hold Support Shaft | RD 9191 | Screw |
| RD 0642 | Screw | RD 5701 | Lever Spring Guide B | RD10252 | Main Shaft |
| RD 0743 | Washer | RD 5703 | Bail Trip Lever | RD10260 | Bail Assembly |
| RD 2298 | Spacer | RD 5704 | Trip Lever Spacer | RD10700 | Handle Screw Cap |
| RD 2409 | Spacer | RD 5705 | Roller Clutch Ring | RD11190 | Drag Knob |
| RD 3232 | Rotor Nut | RD 5706 | Roller Clutch Assembly | RD11191 | Spool Assembly |
| RD 3273 | Handle Screw Lock | RD 5707 | Bearing Washer | RD11192 | Line Safety Guard |
| RD 3304 | Bearing Spacer | RD 5710 | Anti-Reverse Cam | RD11193 | Line Roller Bushing |
| RD 3339 | Spool Support B | RD 5711 | Anti-Reverse Cam Spring | RD11194 | Bail Arm |
| RD 3340 | Spacer | RD 5712 | O Ring | RD11195 | Bail Spring Cover |
| RD 3342 | Screw | RD 5713 | Worm Bushing (front) | RD11196 | Bail Spring |
| RD 3348 | Screw | RD 5716 | Worm Bushing (rear) | RD11197 | Bail Spring Guide B |
| RD 4627 | Screw | RD 5722 | Screw | RD11198 | Rotor |
| RD 4631 | Spacer | RD 5723 | Oscillating Pawl Cover | RD11199 | Bail Hold Support Spacer |
| RD 4718 | Lever Spring Guide A | RD 5724 | Oscillating Slider Bushing | RD11200 | Bail Hold Support Guard |
| RD 4744 | Roller Bearing Seal | RD 5725 | Oscillating Pawl | RD11201 | Side Cover Flange |
| RD 5040 | Screw | RD 5726 | Oscillating Slider | RD11202 | Drive Gear |
| RD 5042 | Anti-Reverse Cam Ring | RD 5727 | Screw | RD11203 | Side Cover |
| RD 5354 | Line Roller | RD 5730 | Worm Shaft Retainer Washer | RD11204 | Handle Assembly |
| RD 5677 | Spool Support A | RD 5753 | Pinion Gear | RD11205 | Rear Protector |
| RD 5678 | Bearing Retainer | RD 5754 | Idle Gear | RD11206 | Anti-Reverse Lever |
| RD 5680 | Spacer | RD 5755 | Worm Shaft | RD11207 | Body |
| RD 5681 | Angle Controller | RD 5761 | Oscillating Guide (long) | RD13188 | Ball Bearing |
| RD 5682 | Bail Arm Nut | RD 5762 | Oscillating Guide (short) | RD13294 | Handle Screw Lock Washer |
| RD 5683 | Bail Spring Guide A Support | RD 5779 | Bushing | RD13381 | Ball Bearing |
| RD 5684 | Bail Spring Guide A | RD 5891 | Bail Trip Lever Spring | RD14101 | Ball Bearing |
| RD 5685 | Spacer | RD 5944 | Screw | RD14396 | Ball Bearing |
| RD 5686 | Bail Arm Shaft | RD 6003 | Line Roller Washer | | |
| RD 5690 | Screw | RD 6802 | Bail Arm Bushing | | |
| RD 5693 | U Lock | RD 8776 | Oil Cap | | |
| RD 5696 | Screw | RD 9162 | Spool Washer | RD11250 | Spare Spool Assembly |