



# SUPER AERO

3000GTM 97

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	4661	Anti-Reverse Cam Ring	5268	Drag Shaft (B)
0041	Drive Gear Washer	4677	Oscillating Slider Bushing	5269	Drag Washer "H" (blue)
0071	Rotor Nut	4678	Oscillating Pawl	5270	Eared Washer "B"
0345	Anti-Reverse Lever Screw	4698	Bail Spring Guide (A)	5271	Drag Coil Spring
0589	Lever Hold Spring	4699	Bail Spring	5272	Drag Spring Washer
0787	Multi-Purpose Screw	4700	Bail Spring Guide (B)	5273	Pressure Screw
0930	Ball Bearing	4702	Bail Arm Bushing	5274	"O" Ring
1008	Handle Lock Washer	4829	Roller Clutch Screw	5275	Hold Click Spring
1442	Handle Screw Cap	4838	Drive Gear Bushing	5276	Lever Click Gear
1504	Multi-Purpose Screw	4839	Drive Gear	5277	Fightin' Pressure Screw Washer
1506	Clutch Cover Screw	4972	Bail Trip Lever	5278	Fightin' Pressure Screw
1520	Anti-Reverse Cam Spring	4999	Line Roller Bushing	5302	Bail Arm
1676	Side Cover Screw	5000	Line Roller Collar	5303	Bail Spring Cover Screw (large)
2298	Spacer	5001	Line Roller Washer	5304	Bail Spring Cover
2346	Drag Washer "C" (cloth)	5222	Idle Gear Lock	5305	Bail Hold Support Guard
2347	Click Gear	5247	Spool Assembly (match)	5306	Bail Hold Support Spacer
2348	Drag Washer "C" (blue)	5248	Spool Assembly (shallow)	5308	Rotor
2353	Drag Programmer Screw	5249	Main Shaft	5309	Pinion Gear
2404	"E" Lock	5251	Roller Clutch Assembly	5310	Bushing
2409	Worm Shaft Spacer	5252	Anti-Reverse Cam	5311	Anti-Reverse Lever
2852	Handle Screw Lock	5253	Oscillating Guide	5312	Side Cover Flange
3655	Bail Spring Cover Screw (small)	5254	Worm Bushing	5313	Side Cover
4403	Line Roller Screw	5255	Worm Shaft	5314	Rear Cover Screw (short)
4490	Double Paddle Handle Assembly	5256	Idle Gear	5315	Rear Cover
4631	Spacer	5257	Oscillating Guide Retainer	5316	Fightin' Drag II Lever
4649	Spacer	5261	Slider Retainer Screw	5317	Drag Programmer
4650	Bail Hold Support Shaft	5262	Oscillating Slider Retainer	5318	Body
4652	Lever Spring Guide (B)	5263	Oscillating Slider	5350	Line Roller
4653	Lever Spring	5264	Eared Washer "Br"	5367	Bail Assembly
4654	Lever Spring Guide (A)	5266	Drag Washer "H" (cloth)	5545	Bail Arm Screw
4656	Trip Lever Spacer	5267	Drag Shaft (A)		