



## 4000FE 97

| RD No. | PARTS NAMES                     | RD No. | PARTS NAMES                     | RD No. | PARTS NAMES             |
|--------|---------------------------------|--------|---------------------------------|--------|-------------------------|
| 0026   | Ball Bearing                    | 4650   | Bail Hold Support Shaft         | 4833   | Worm Bushing (front)    |
| 0041   | Drive Gear Washer               | 4652   | Lever Spring Guide (B)          | 4836   | Worm Bushing (rear)     |
| 0071   | Rotor Nut                       | 4654   | Lever Spring Guide (A)          | 4838   | Drive Gear Bushing      |
| 0787   | Multi-Purpose Screw             | 4656   | Trip Lever Spacer               | 4842   | Oscillating Guide (A)   |
| 0930   | Ball Bearing                    | 4661   | Anti-Reverse Cam Ring           | 4843   | Oscillating Guide (B)   |
| 1008   | Handle Lock Washer              | 4675   | Oscillating Pawl Cover Screw    | 4844   | Worm Shaft Retainer     |
| 1506   | Clutch Cover Screw              | 4677   | Oscillating Slider Bushing      | 4974   | Idle Gear               |
| 1520   | Anti-Reverse Cam Spring         | 4678   | Oscillating Pawl                | 4999   | Line Roller Bushing     |
| 1891   | Multi-Purpose Screw             | 4698   | Bail Spring Guide (A)           | 5000   | Line Roller Collar      |
| 2298   | Spacer                          | 4699   | Bail Spring                     | 5001   | Line Roller Washer      |
| 2309   | Slider Retainer Screw           | 4700   | Bail Spring Guide (B)           | 5017   | Pinion Gear             |
| 2362   | Spool Support                   | 4702   | Bail Arm Bushing                | 5018   | Bushing                 |
| 2404   | "E" Lock                        | 4704   | Bail Spring Cover Screw (large) | 5019   | Worm Shaft              |
| 2852   | Handle Screw Lock               | 4710   | Lever Spring                    | 5020   | Side Cover Flange       |
| 3309   | Line Roller Screw               | 4711   | Bail Trip Lever                 | 5021   | Drive Gear              |
| 3366   | Anti-Reverse Lever Screw        | 4714   | Roller Clutch Assembly          | 5022   | Side Cover              |
| 3402   | Bail Spring Cover Screw (small) | 4733   | Oscillating Pawl Cover          | 5023   | Body                    |
| 3414   | Drag Knob                       | 4734   | Oscillating Slider              | 5025   | Rear Protector          |
| 3468   | Rear Cover Screw (short)        | 4803   | Worm Shaft Spacer               | 5027   | Spool Assembly          |
| 3503   | Spool Washer                    | 4810   | Rear Protector Screw            | 5028   | Bail Spring Cover       |
| 4362   | Side Cover Screw                | 4822   | Main Shaft                      | 5029   | Bail Hold Support Guard |
| 4421   | Handle Screw Cap                | 4823   | Bail Arm                        | 5030   | Rotor                   |
| 4449   | Anti-Reverse Lever              | 4826   | Bail Hold Support Spacer        | 5031   | Rear Cover              |
| 4460   | Handle Assembly                 | 4827   | Bail Assembly                   | 5354   | Line Roller             |
| 4631   | Spacer                          | 4829   | Roller Clutch Screw             | 5542   | Bail Arm Screw          |
| 4649   | Spacer                          | 4832   | Anti-Reverse Cam                |        |                         |