


SAHARA



6000FA

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0050	Anti-Reverse Lever Screw	5449	Anti-Reverse Cam	6757	Nut Retainer
0521	Rotor Nut	5455	Anti-Reverse Cam Spring	6758	Main Shaft
0690	Drive Gear Washer	5625	Line Roller Spacer	6760	Bail Spring Guide (A) Collar
0806	Bail Hold Support Screw	5628	Line Roller Collar	6761	Bail Spring
0998	Rotor Protector Screw (large)	5629	Line Roller Bushing	6764	Spacer
1008	Handle Lock Washer	5642	Line Roller	6767	Bail Trip Lever Spring
1109	Slider Retainer Screw	5823	Lever Spring Guide (A)	6768	Roller Clutch Screw Washer
1506	Clutch Cover Screw	5825	Lever Spring Guide (B)	6769	Pinion Gear
3182	Spool Support	5880	Nut Retainer Screw	6770	Bushing
3204	Ball Bearing	6377	Main Shaft Spacer	6771	Drive Gear
3309	Line Roller Screw	6379	Bail Arm Screw	6772	Drive Gear Spacer
3387	Handle Screw Lock	6380	Bail Spring Guide (A)	6774	Oscillating Slider
3503	Spool Washer	6383	Bail Spring Guide (B)	6775	Oscillating Gear
4362	Side Cover Screw (long)	6539	Bail Trip Lever	6776	Oscillating Gear Bushing
4416	Rotor Protector Screw (small)	6540	Bail Hold Support Spacer	6782	Bail Assembly
4649	Spacer	6639	Side Cover Screw (short)	6783	Handle Screw Cap
4656	Trip Lever Spacer	6676	Bail Arm	6784	Handle Assembly
5040	Roller Clutch Screw	6686	Click Spring	6785	Body Assembly
5042	Anti-Reverse Cam Ring	6687	Bail Arm Click	6786	Rotor Assembly
5208	Anti-Reverse Lever	6692	Bail Hold Support Shaft	6843	Friction Ring
5440	Drag Knob	6703	Line Roller Washer		
5447	Roller Clutch Assembly	6756	Spool Assembly		

(120711)