



TWIN POWER 4000XTR 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	5257	Oscillating Guide Retainer	6355	Bail Spring Guide (B)
0041	Drive Gear Washer	5261	Slider Retainer Screw	6359	Bail Trip Lever
0050	Anti-Reverse Lever Screw	5262	Oscillating Slider Retainer	6414	Protector Screw (large)
0071	Rotor Nut	5263	Oscillating Slider	6430	Protector Screw (small)
0589	Lever Hold Spring	5264	Eared Washer "B"	6440	Bail Spring Cover
0806	Bail Hold Support Screw	5266	Drag Washer "H" (cloth)	6441	Bail Arm
0930	Ball Bearing	5269	Drag Washer "H" (blue)	6442	Rotor Protector
1008	Handle Lock Washer	5270	Eared Washer "B"	6443	Bail Assembly
1506	Clutch Cover Screw	5275	Hold Click Spring	6597	Side Cover Screw (small)
1520	Anti-Reverse Cam Spring	5276	Lever Click Gear	6603	Drive Gear
2094	Spacer	5277	Fightin' Pressure Screw Washer	6606	Side Cover Screw (medium)
2254	Ball Bearing	5278	Fightin' Pressure Screw	6894	Oscillating Slider Bushing
2298	Spacer	5338	Drag Washer "C" (cloth)	6898	Rear Cover Screw (short)
2346	Drag Washer "C" (cloth)	5339	Drag Shaft (B)	6918	Rotor
2347	Click Gear	5340	Key Washer "A"	6919	Roller Clutch Assembly
2348	Drag Washer "C" (blue)	5341	Drag Coil Spring	6920	Spacer
2409	Worm Shaft Spacer	5342	Drag Spring Washer	6922	Worm Bushing
2419	Handle Screw Cap	5343	Pressure Screw	6923	Worm Shaft
2852	Handle Screw Lock	5344	Hold Click Spring Washer	6924	Anti-Reverse Cam
3282	Roller Clutch Screw	5880	Nut Lock Screw	6925	Idle Gear
3306	Ball Bearing	6077	Click Pin	6926	Anti-Reverse Lever
3309	Line Roller Screw	6085	Line Roller	6927	Rear Cover Screw (long)
3436	Drag Programmer Screw	6132	Friction Ring	6930	Body
4362	Side Cover Screw (long)	6290	Rotor Nut Lock Plate	6932	Drag Shaft (A)
4652	Lever Spring Guide (B)	6296	Click Spring	6933	Fightin' Drag II Lever
4653	Lever Spring	6307	Bail Hold Support Shaft	6934	Drag Programmer
4654	Lever Spring Guide (A)	6308	Bail Hold Support Spacer	6935	Spool Assembly
4656	Trip Lever Spacer	6329	Bearing Spacer	6936	Match Spool Assembly
4678	Oscillating Pawl	6330	Line Roller Bushing	6937	Main Shaft
4724	Ball Bearing	6331	Line Roller Spacer	6938	Side Cover Assembly
4749	Bail Arm Screw	6332	Line Roller Washer	6939	Handle Assembly
5222	Idle Gear Lock	6353	Bail Spring Guide (A)	6940	Rear Cover
5253	Oscillating Guide	6354	Bail Spring	7284	Pinion Gear