



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0642	Screw	8880	Drag Knob Washer	13066	Oscillating Guide
0786	Screw	8881	Drag Knob Retainer	13067	Idle Gear
1514	Washer	8882	Click Plate Retainer	13072	Oscillating Slider Retainer
2298	Spacer	8883	Click Plate	13073	Oscillating Slider Bushing
2346	Drag Washer	8886	Drag Coil Spring	13074	Oscillating Slider
2347	Click Gear	8916	Click Spring	13079	Drag Shaft A
2348	Drag Washer	9841	Click Pin	13080	Lever Click Gear
2349	Eared Washer	9856	Washer	13081	Fightin' Pressure Screw
2409	Spacer	9863	Friction Spring	13082	Fightin' Pressure Screw B
3177	Key Washer	9872	Screw	13083	Fightin' Lever Inner B
3179	Eared Washer	10000	Line Roller	13084	Fightin' Lever Inner A
3503	Spool Washer	10011	Screw	13085	Fightin' Lever Outer
3561	Screw	10345	Drag Washer	13087	Drag Programmer B
3775	Drag Click	10385	Key Washer	13178	Oil Cap
4150	Screw	10388	Spool Support	13241	Ball Bearing
4798	Screw	10483	Handle Screw Cap	13260	Drag Shaft B
4812	Screw	10752	Spring Guide A Support	13269	Ball Bearing
5266	Drag Washer	10753	Bail Spring	13369	Drag Knob
5269	Drag Washer	10893	Position Pin Spring	13370	Spool Assembly
5270	Eared Washer	10894	Lever Position Pin	13371	Main Shaft
5340	Key Washer	10996	Rotor Nut	13372	Bail Arm
6016	Bearing Spacer	11077	Drag Washers Retainer	13373	Rotor
6017	Line Roller Bushing	11080	Anti-Reverse Cam Spring	13374	Ball Bearing
6019	Line Roller Plate	11146	Washer	13375	Pinion Gear
6482	Screw	11547	Line Roller Support	13376	Worm Shaft
6597	Screw	12584	Washer	13377	Drive Gear
7417	Screw	12585	Roller Clutch Assembly	13378	Side Cover
7469	Screw	12587	Friction Ring	13379	Handle Assembly
7583	E Lock	12588	Anti-Reverse Cam	13380	Body
7787	Bail Spring Guide A	12609	Bail Trip Lever	13381	Ball Bearing
7869	Screw	12612	Bail Assembly	13382	Drag Shaft C
8171	Washer	12613	Bail Hold Support Shaft	13383	Rear Protector
8778	Oscillating Pawl	12614	Bail Hold Support Spacer	13384	Drag Programmer A
8787	Click Pin	12617	Bail Trip Strike	13385	Drag Programmer Assembly
8788	Click Spring	12686	Bail Spring Cover	15062	Fightin' Lever Assembly
8854	Worm Shaft Pin	12688	Bail Hold Support Guard		
8869	Drag Washer	13061	Washer		
8870	Pressure Screw	13063	Worm Bushing		
8872	Fightin' Pressure Screw Washer	13064	Anti-Reverse Lever	11293	Wrench (accessory)
8877	Drag Knob Friction Ring	13065	Anti-Reverse Lever Cover	13092	Knob Wrench (accessory)