

STRADIC 4000GTM

97

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	4661	Anti-Reverse Cam Ring	5258	Anti-Reverse Lever
0041	Drive Gear Washer	4677	Oscillating Slider Bushing	5259	Side Cover Flange
0050	Anti-Reverse Lever Screw	4678	Oscillating Pawl	5260	Side Cover
0071	Rotor Nut	4698	Bail Spring Guide (A)	5261	Slider Retainer Screw
0589	Lever Hold Spring	4699	Bail Spring	5262	Oscillating Slider Retainer
0787	Multi-Purpose Screw	4700	Bail Spring Guide (B)	5263	Oscillating Slider
0930	Ball Bearing	4702	Bail Arm Bushing	5264	Eared Washer "BF"
1008	Handle Lock Washer	4704	Bail Spring Cover Screw (large)	5266	Drag Washer "H" (cloth)
1506	Clutch Cover Screw	4710	Lever Spring	5267	Drag Shaft (A)
1520	Anti-Reverse Cam Spring	4711	Bail Trip Lever	5268	Drag Shaft (B)
1891	Multi-Purpose Screw	4823	Bail Arm	5269	Drag Washer "H" (blue)
2298	Spacer	4824	Bail Spring Cover	5270	Eared Washer "B"
2346	Drag Washer "C" (cloth)	4825	Bail Hold Support Guard	5271	Drag Coil Spring
2347	Click Gear	4826	Bail Hold Support Spacer	5272	Drag Spring Washer
2348	Drag Washer "C" (blue)	4829	Roller Clutch Screw	5273	Pressure Screw
2404	"E" Lock	4830	Pinion Gear	5274	"O" Ring
2409	Worm Shaft Spacer	4831	Ball Bearing	5275	Hold Click Spring
2852	Handle Screw Lock	4838	Drive Gear Bushing	5276	Lever Click Gear
3081	Side Cover Screw	4839	Drive Gear	5277	Fightin' Pressure Screw Washer
3309	Line Roller Screw	4999	Line Roller Bushing	5278	Fightin' Pressure Screw
3402	Bail Spring Cover Screw (small)	5000	Line Roller Collar	5279	Fightin' Drag II Lever
3436	Drag Programmer Screw	5001	Line Roller Washer	5280	Drag Programmer
3468	Rear Cover Screw (short)	5222	Idle Gear Lock	5281	Body
4421	Handle Screw Cap	5249	Main Shaft	5282	Spool Assembly (match)
4470	Double Paddle Handle Assembly	5251	Roller Clutch Assembly	5283	Spool Assembly (shallow)
4631	Spacer	5252	Anti-Reverse Cam	5284	Rotor
4649	Spacer	5253	Oscillating Guide	5285	Rear Cover
4650	Bail Hold Support Shaft	5254	Worm Bushing	5350	Line Roller
4652	Lever Spring Guide (B)	5255	Worm Shaft	5357	Bail Assembly
4654	Lever Spring Guide (A)	5256	Idle Gear	5542	Bail Arm Screw
4656	Trip Lever Spacer	5257	Oscillating Guide Retainer		

(080913)