SHIMANO®

SUPER AERO

SUA-4000HS



Part No.	Description	Part No.	Description	Part No.	Description
RD0041	Drive Gear Washer	RD2346	Drag Washer “C” (cloth)	RD3810	Anti-Reverse Pawl
RD0050	Anti-Reverse Lever Screw	RD2404	“E” Lock	RD3811	Anti-Reverse Cam (A)
RD0071	Rotor Nut	RD2406	Drive Gear	RD4239	Drag Spring Washer “A”
RD0111	Drag Coil Spring	RD2428	Pinion Gear	RD4627	Side Cover Screw (large)
RD0540	Multi-Purpose Screw	RD2432	Drag Shaft	RD4631	Spacer
RD0584	Hold Click Spring	RD2433	Pressure Screw	RD4743	Line Roller Bushing
RD0642	Side Cover Screw (small)	RD2852	Handle Screw Lock	RD4744	Roller Bearing Seal
RD0779	Bail Arm Screw	RD3125	Drag Click Screw	RD7723	Handle Screw Cap
RD0787	Nut Lock Screw	RD3130	Main Shaft	RD7730	Bail Arm
RD0826	Key Washer “A”	RD3304	Bearing Spacer	RD7731	Bail Spring Cover
RD1008	Handle Lock Washer	RD3308	Line Roller Washer	RD7741	Counterbalance Cover
RD1509	Bail Spring	RD3309	Line Roller Screw	RD7742	Rotor
RD1511	Lever Spring	RD3402	Cover Screw	RD7743	Line Roller
RD1520	Anti-Reverse Cam (A) Spring	RD3506	Bail Spring Guide (A)	RD7744	Bail Assembly
RD1890	Bushing Washer	RD3507	Bail Spring Guide (B)	RD7746	Handle Assembly
RD1891	Bearing Retainer Screw	RD3509	Bail Trip Lever	RD7768	Anti-Reverse Lever
RD2016	Drag Washer “H” (cloth)	RD3518	Anti-Reverse Pawl Screw	RD7770	Drag Knob
RD2108	Eared Washer “B”	RD3521	Anti-Reverse Pawl Spacer	RD7780	Spool Assembly
RD2257	Drag Washer “H” (blue)	RD3775	Drag Click	RD7781	Side Cover
RD2298	Spacer	RD3794	Drag Knob Screw	RD7782	Body
RD2299	Oscillating Slider Bushing	RD3803	Lock Out Spring Holder	RD7909	Worm Shaft Spacer
RD2300	Oscillating Pawl	RD3804	Anti-Reverse Lock Out Spring	RD7911	Idle Gear
RD2309	Slider Retainer Screw	RD3805	Anti-Reverse Lock Out	RD8373	Line Roller Bearing
RD2336	Worm Bushing	RD3806	Bearing Retainer	RD8553	Ball Bearing
RD2339	Worm Shaft	RD3807	Anti-Reverse Cam (B)	RD8554	Ball Bearing
RD2343	Oscillating Slider Retainer	RD3808	Anti-Reverse Cam (B) Spring		
RD2344	Oscillating Slider	RD3809	Anti-Reverse Pawl Spring		