# SHIMANO

## TIAGRA D3 SA-RB

## TI-50WLRSD3



Please note that the number of adjusting washers may not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

(1RJ202052U)

| Part No. | Description | Part No. | Description | Part No. | Description |
|---|---|---|---|---|---|
| TT 0003A | Handle Bolt | TT 0301 | Dog Spring | TT 0825 | Drag Lever Knob A |
| TT 0006A | Drive Shaft Washer | TT 0302 | Set Plate | TT 0828 | Harness Lug |
| TT 0013 | C Lock | TT 0303 | Dog | TT 0829 | Ball Bearing |
| TT 0036 | Cross Pin A | TT 0304 | Set Plate Support | TT 0834 | Shaft Holder |
| TT 0036C | Cross Pin B | TT 0308 | Lever Shaft Body | TT 0837 | C Lock |
| TT 0040 | Pre-Load Spring | TT 0313 | Lever Thrust Ring | TT 0839 | Washer |
| TT 0041C | Pre-Load Washer | TT 0376 | Screw | TT 0840 | Screw |
| TT 0045B | Pressure Plate Spring | TT 0563 | Screw | TT 0841 | Anti-Reverse Ratchet |
| TT 0093 | Slide Plate Spring | TT 0579 | O Ring | TT 0843 | Screw |
| TT 0096 | E Lock | TT 0593 | Lever Click Cover | TT 0845 | Screw |
| TT 0102 | Friction Washer A | TT 0594 | Screw | TT 0860 | Lever Quadrant |
| TT 0103 | Friction Washer B | TT 0641 | Screw | TT 0861 | Drag Control Lever |
| TT 0105 | Gear Select Cross Bar | TT 0645 | Screw | TT 0862 | Right Side Plate B |
| TT 0106 | Cross Bar Stop | TT 0671 | Lever Click Shoe | TT 0863 | Right Side Plate |
| TT 0107 | Drive Shaft Spring B | TT 0672 | Lever Click | TT 0864 | Spool |
| TT 0108 | Drive Shaft Spring | TT 0683 | Click Spring | TT 0865 | Main Shaft |
| TT 0110 | E Lock | TT 0684 | Plunger Cross Pin A | TT 0866 | Pressure Plate |
| TT 0114A | Washer | TT 0702 | Push Low Button Shaft | TT 0867 | Cooling Shield |
| TT 0156 | Friction Shoe Spring | TT 0704 | Screw | TT 0868 | One-Piece Frame |
| TT 0249 | Drive Shaft Shield | TT 0706 | Screw | TT 0869 | Left Side Plate Frame Assembly |
| TT 0252 | Lever Hub Cover | TT 0708 | Strike Stop | TT 0870 | Battery Cover |
| TT 0255 | Pre-Program Dial | TT 0709 | Pressure Spring | TT 0871 | Left Side Plate |
| TT 0256 | Dial Click Shoe | TT 0711 | Free Spool Detent | TT 0872 | Counter Guard |
| TT 0257 | Dial Click | TT 0712 | Screw | | |
| TT 0258 | Washer | TT 0713 | Screw | | |
| TT 0259 | Lever Thrust Ring | TT 0714 | Washer | TT 0391 | Rod Clamp Nut B (accessory) |
| TT 0261 | Lever Thrust Ring | TT 0716 | O Ring | TT 0392 | Rod Clamp (accessory) |
| TT 0267 | Screw | TT 0718 | Plunger Holder | TT 0393 | Rod Clamp Nut A (accessory) |
| TT 0269 | Pre-Program Key | TT 0719 | Alert Plunger | TT 0803 | Rod Clamp Bolt (accessory) |
| TT 0270 | Pre-Program Key Pin | TT 0720 | Alert Ratchet | | |
| TT 0271 | Pre-Program Screw | TT 0722 | Drag Plate | TT 0846 | Screw (accessory) |
| TT 0274 | Plunger Cross Pin B | TT 0755 | Screw | TT 0847 | Lever Stopper Knob (accessory) |
| TT 0275 | Plunger Cross Pin Support | TT 0763 | Bearing Thrust Washer | TT 0848 | Lever Stopper Pin Spring (accessory) |
| TT 0276 | Cross Pin Support Spring | TT 0764 | Spacer | TT 0849 | Lever Stopper Pin (accessory) |
| TT 0279 | Holder Nut | TT 0769 | Handle Knob Bushing | TT 0850 | Lever Stopper Holder (accessory) |
| TT 0280 | Drive Shaft Holder | TT 0796 | Screw | TT 0851 | Lever Stopper Unit (accessory) |
| TT 0281 | Lock Pin | TT 0812 | Strike Alert Lever | TT 0852 | Lever Quadrant Marking A (accessory) |
| TT 0282 | Drive Gear A | TT 0814 | Screw | TT 0853 | Lever Quadrant Marking B (accessory) |
| TT 0283 | Drive Gear B | TT 0815 | Push Button Shield | TT 0854 | Lever Quadrant Marking C (accessory) |
| TT 0284 | Drive Shaft | TT 0816 | Slide Plate | TT 0855 | Lever Quadrant Marking D (accessory) |
| TT 0285 | Drive Shaft Screw | TT 0817 | Handle Bolt Plate B | | |
| TT 0286 | Pinion Gear A | TT 0818 | Handle Bolt Plate A | TT 0146 | Wrench (accessory) |
| TT 0287 | Pinion Gear B | TT 0819 | Slide Plate Guide Pin | TT 0856 | Screw Driver (accessory) |
| TT 0290 | Piston Assembly | TT 0820 | Slide Plate Spring Guide | TT 0857 | Safety Strap (accessory) |
| TT 0295 | Drag Washer | TT 0821 | Handle Assembly | TT 0858 | Bobbin with Line (accessory) |
| TT 0300 | Screw | TT 0824 | Drag Lever Knob B | TT 0859 | Battery Case Unit (accessory) |